

# YZF-R1V YZF-R1VC YZF-R1LEV YZF-R1LEVC

# SUPPLEMENTARY SERVICE MANUAL

5VY-28197-11

# FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and data for the YZF-R1V/YZF-R1VC/YZF-R1LEV/YZF-R1LEVC. For complete service information procedures it is necessary to use this Supplementary Service Manual together with the following manual.

#### YZF-R1S/YZF-R1SC SERVICE MANUAL: LIT-11616-17-55 (5VY-28197-10)

EAS00001

YZF-R1V/YZF-R1VC YZF-R1LEV/YZF-R1LEVC SUPPLEMENTARY SERVICE MANUAL ©2005 by Yamaha Motor Corporation, U.S.A. First edition, October 2005 All rights reserved. Any reproduction or unauthorized use without the written permission of Yamaha Motor Corporation, U.S.A. is expressly prohibited. Printed in U.S.A. LIT-11616-19-75 EAS00030

# NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

#### NOTE: .

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

EAS00040

#### IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.

The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

- **A WARNING** Failure to follow WARNING instructions <u>could result in severe injury or death</u> to the vehicle operator, a bystander or a person checking or repairing the vehicle.
- **CAUTION:** A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

EAS00007

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

(1) The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to "SYMBOLS".

② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 ("PERIODIC CHECKS AND ADJUSTMENTS"), where the sub-section title(s) appears.

③ Sub-section titles appear in smaller print than the section title.

(4) To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

(5) Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.

(6) Symbols indicate parts to be lubricated or replaced. Refer to "SYMBOLS".

 $\bigcirc$  A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.

(8) Jobs requiring more information (such as special tools and technical data) are described sequentially.





# SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols (1) to (9) indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- (4) Chassis
- 5 Engine
- 6 Cooling system
- Fuel injection system
- 8 Electrical system
- (9) Troubleshooting
- Symbols 10 to 17 indicate the following.
- 0 Serviceable with engine mounted
- 1 Filling fluid
- 12 Lubricant
- (13) Special tool
- 14 Tightening torque
- (15) Wear limit, clearance
- 16 Engine speed
- 17 Electrical data

Symbols (18) to (23) in the exploded diagrams indicate the types of lubricants and lubrication points.

- 18 Engine oil
- 19 Gear oil
- Molybdenum-disulfide oil
- (1) Wheel-bearing grease
- 2 Lithium-soap-based grease
- 23 Molybdenum-disulfide grease

Symbols (2) to (2) in the exploded diagrams indicate the following.

24 Apply locking agent (LOCTITE<sup>®</sup>)

25 Replace the part with a new one.

# CONTENTS

GENERAL INFORMATION	
SPECIAL TOOLS	1
SPECIFICATIONS	
GENERAL SPECIFICATIONS	2
ENGINE SPECIFICATIONS	3
CHASSIS SPECIFICATIONS.	4
ELECTRICAL SPECIFICATIONS	7
	7
ENGINE TIGHTENING TORQUES	7
CHASSIS TIGHTENING TORQUES	8
LUBRICATION POINTS AND LUBRICANT TYPES	9
ENGINE	9
CHASSIS	9
LUBRICATION DIAGRAMS	10
	11

#### PERIODIC CHECKS AND ADJUSTMENTS

27
27
27
29
29
32

#### CHASSIS

FRONT WHEEL AND BRAKE DISCS	35
REAR WHEEL AND BRAKE DISCS	36
REAR BRAKE DISC AND REAR WHEEL SPROCKET	36
FRONT FORK	38
FRONT FORK LEGS	38
DISASSEMBLING THE FRONT FORK LEGS	40
CHECKING THE FRONT FORK LEGS	42
ASSEMBLING THE FRONT FORK LEGS	43
REAR SHOCK ABSORBER ASSEMBLY	47
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY	49
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	50
SWINGARM AND DRIVE CHAIN	51
REMOVING THE SWINGARM	51
CHECKING THE SWINGARM	52
CHECKING THE CONNECTING ROD ASSEMBLY	53
CHECKING THE DRIVE CHAIN	54

#### ENGINE

ENGINE	56
INSTALLING THE ENGINE	58
CAMSHAFTS	60
CLUTCH	61
CLUTCH COVER	61
CLUTCH	62
REMOVING THE CLUTCH	66
CHECKING THE FRICTION PLATES	67
CHECKING THE CLUTCH PLATES	68
CHECKING THE CLUTCH SPRINGS	69
CHECKING THE CLUTCH HOUSING	69
CHECKING THE PRESSUR PLATE 2	70
CHECKING THE CLUTCH BOSS	70
CHECKING THE PRESSURE PLATE 1	70
CHECKING THE PULL LEVER SHAFT AND PULL ROD	71
INSTALLING THE CLUTCH	71

YZF-R1V/YZF-R1VC/YZF-R1LEV/YZF-R1LEVC 2006 WIRING DIAGRAM



#### EAS00027

# **GENERAL INFORMATION**

# SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.

When placing an order, refer to the list provided below to avoid any mistakes.

#### NOTE: \_

- For U.S.A. and Canada, use part number starting with "YM-", "YU-", or "ACC-".
- For others, use part number starting with "90890-".

#### (YZF-R1LE)

Tool No.	Tool name/Function	Illustration
90890-01472	Front fork cap bolt wrench This tool is used to loosen or tighten the front fork cap bolt.	
90890-01504	Damper rod holder This tool is used to loosening or tightening the damper rod assembly.	
Rod puller 90890-01437 YM-A8703 Rod puller attachment 90890-01435 YM-A8703	Rod puller Rod puller attachment These tools are used to pull up the front fork damper rod.	60-



# SPECIFICATIONS

## **GENERAL SPECIFICATIONS**

Item	Standard	Limit
Model code	YZF-R1 5VYH (USA), 5VYL (USA) 5VYJ (CAL), 5VYM (CAL) YZF-R1LE 4B14 (USA), 4B15 (CAL)	•••
Dimensions		
Overall length	2,085 mm (82.1 in)	•••
Wheelbase	1,415 mm (55.7 in)	•••
Weight		
Wet (with oil and a full fuel tank)	194 kg (428 lb) (USA) (YZF-R1)	•••
	195 kg (430 lb) (CAL) (YZF-R1)	•••
	195 kg (430 lb) (USA) (YZF-R1LE)	•••
	195 kg (430 lb) (CAL) (YZF-R1LE)	•••
Maximum load (except vehicle)	201 kg (443 lb) (USA) (YZF-R1)	•••
	200 kg (441 lb) (CAL) (YZF-R1)	•••
	200 kg (441 lb) (USA) (YZF-R1LE)	•••
	200 kg (441 lb) (CAL) (YZF-R1LE)	•••



#### **ENGINE SPECIFICATIONS**

Item	Standard	Limit
Oil pump		
Oil-pump-housing-to-inner-and-outer-	0.06 ~ 0.13 mm	0.20 mm
rotor clearance	(0.0024 ~ 0.0051 in)	(0.0079 in)
Cylinder head		, ,
Volume	$12.3 \sim 12.9 \text{ cm}^3 (0.75 \sim 0.79 \text{ cu in})$	•••
Max warpage	•••	0 10 mm
Max. Walpage		(0, 00.39  in)
al-		
Piston		
Diameter D	$76.975 \sim 76.990 \text{ mm} (3.0305 \sim 3.0311 \text{ in})$	•••
· · · · · · · · · · · · · · · · · · ·		
/ <b>→</b> D─ <b>→</b> /		
Height H	12 mm (0.47 in)	•••
Clutch		
Friction plates		
Color code	Red	•••
Thickness	2.9 ~ 3.1 mm (0.114 ~ 0.122 in)	2.8 mm
		(0.110 in)
Plate quantity	7	•••
Color code	Red	•••
Thickness	2.9 ~ 3.1 mm (0.114~ 0.122 in)	2.8 mm
		(0.110 in)
Plate quantity	1	•••
Color code	Red	•••
Thickness	2.9 ~ 3.1 mm (0.114 ~ 0.122 in)	2.8 mm
		(0.110 in)
Plate quantity	1	•••
Clutch plates		
Thickness	1.9 ~ 2.1 mm (0.07 ~ 0.08 in)	•••
Plate quantity	8	•••
Max. warpage	•••	0.1 mm
		(0.0039 in)
Clutch springs		
Free length	43.8 mm (1.72 in) (YZF-R1LE)	41.6 mm
		(1.64 in)
Throttle bodies		
ID mark	5VY1 30 (USA), 5VY1 40 (CAL)	•••



#### **CHASSIS SPECIFICATIONS**

Item	Standard	Limit
Front wheel		
Wheel type	Forged wheel (YZF-R1LE)	•••
Rear wheel		
Wheel type	Forged wheel (YZF-R1LE)	•••
Front tire		
Model (manufacturer)	Pilot POWER (MICHELIN) (YZF-R1)	•••
	D218FG (DUNLOP) (YZF-R1)	•••
<del>-</del>	DIABLO CORSA H (PIRELLI) (YZF-R1LE)	•••
l ire pressure (cold)		
90 ~ 201 kg (198 ~ 443 lb)	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar, 35.6 psi) (USA) (YZF-R1)	•••
90 ~ 200 kg (198 ~ 441 lb)	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar, 35.6 psi)	•••
90 ~ 200 kg (198 ~ 441 lb)	$(250 \text{ kPa} (2.5 \text{ kgf/cm}^2, 2.5 \text{ bar}, 35.6 \text{ psi})$	•••
	(USA) (YZF-R1LE)	
90 ~ 200 kg (198 ~ 441 lb)	250 kPa (2.5 kgf/cm <sup>2</sup> , 2.5 bar, 35.6 psi)	•••
De en tine		
Rear tire		
Model (manulacturer)		••••
	(121 - 111) (121 - 111) (121 - 111) (121 - 111) (121 - 111)	•••
	DIABLO CORSA (PIRELLI) (VZE-R1LE)	•••
Tire pressure (cold)		
$90 \sim 201 \text{ kg} (198 \sim 443 \text{ lb})$	290 kPa (2.9 kgf/cm <sup>2</sup> , 2.9 bar, 41.3 psi)	•••
	(USA) (YZF-R1)	
90 ~ 200 kg (198 ~ 441 lb)	290 kPa (2.9 kgf/cm <sup>2</sup> , 2.9 bar, 41.3 psi)	•••
	(CAL) (YZF-R1)	
90 ~ 200 kg (198 ~ 441 lb)	290 kPa (2.9 kgf/cm <sup>2</sup> , 2.9 bar, 41.3 psi)	•••
	(USA) (YZF-R1LE)	
90 ~ 200 kg (198 ~ 441 lb)	290 kPa (2.9 kgt/cm <sup>2</sup> , 2.9 bar, 41.3 psi) (CAL) (YZF-R1LE)	•••

# **CHASSIS SPECIFICATIONS**



Item	Standard	Limit
Front brakes		
Master cylinder inside diameter	16 mm (0.63 in)	•••
Caliper cylinder inside diameter	30.2 mm and 27 mm (1.19 in and 1.06 in)	•••
Front suspension		
(YZF-R1)		
Fork oil		
Quantity (each front fork leg)	0.52 L (0.46 Imp qt, 0.55 US qt)	•••
Level (from the top of the outer tube,	90 mm (3.54 in)	•••
with the outer tube fully compressed,		
and without the fork spring)		
Spring preload adjusting positions		
Minimum	8	•••
Standard	4.5	•••
Maximum	0	•••
(YZF-R1LE)		
Spring		054.0
Free length	260 mm (10.24 in)	254.8 mm
Coller length	40  mm (1  GEQ in)	(10.03 m)
Lostallod longth	(42  mm (1.053  m))	
Spring rate (K1)	9.50  N/mm (0.97  kg/mm 54.22  lb/in)	•••
Fork oil	9.30 N/min (0.37 Kg/min, 34.22 lb/lin)	
Recommended oil	Suspension oil "Ohlins B&T 43"	•••
	(ACC-BT43F-00-00)	
Quantity (each front fork leg)	0.43 L (0.38 Imp at. 0.45 US at)	•••
Level (from the top of the outer tube,	145 mm (5.71 in)	•••
with the outer tube fully compressed,		
and without the fork spring)		
Spring preload adjusting positions		
Minimum*	11 turns out*	•••
Maximum*	2 turns in*	•••
*from the standard position		
Rebound damping adjusting positions		
Minimum**	17	•••
Standard**	12	•••
Maximum**	1	•••
Compression damping adjusting		
positions	00	
Iviinimum"" Stondord**	20	
Stanuaru Movimum**	12	
**from the fully turned in direction	'	
nom the fully turned-in direction		

# **CHASSIS SPECIFICATIONS**



Item	Standard	Limit
Rear suspension		
(YZF-R1)		
Spring preload adjusting positions		
Minimum	1	•••
Standard	5	•••
Maximum	9	•••
(YZF-R1LE)		
Spring		
Free length	150.0 mm (5.91 in)	•••
Installed length	139.0 mm (5.47 in)	•••
Spring rate (K1)	95.0 N/mm (9.68 kg/mm, 542.18 lb/in)	•••
Spring preload adjusting positions		
Minimum*	0	•••
Standard*	6	•••
Maximum*	20	•••
Rebound damping adjusting positions		
Minimum*	18	•••
Standard*	14	•••
Maximum*	1	•••
Compression damping adjusting		
positions (fast compression damping)		
Minimum*	42	•••
Standard*	30	•••
Maximum*	1	•••
Compression damping adjusting		
positions (slow compression damping)		
Minimum*	17	•••
Standard*	10	•••
Maximum*	1	•••
*from the fully turned-in position		
Drive chain		
Model (manufacturer)	50VA8 (DAIDO)	•••
Link quantity	118	•••
Drive chain slack	20 ~ 25 mm (0.79 ~ 0.98 in)	•••
Maximum 15-link section	•••	239.3 mm
		(9.42 in)



## **ELECTRICAL SPECIFICATIONS**

Item	Standard	Limit
Ignition system T.C.I. unit model (manufacturer)	F8T82075 (MITSUBISHI)	•••
<b>Battery</b> Manufacturer Ten hour rate amperage	GS-YUASA 0.9 A	•••

# **TIGHTENING TORQUES**

**ENGINE TIGHTENING TORQUES** 

ltom	Factoror	Thread	O'ty	Tightening torque			Pomarka
item	i asteriei	size	Qiy	Nm	m•kg	ft∙lb	TICHIAINS
Exhaust pipe and exhaust valve pipe	Bolt	M6	5	12	1.2	8.7	
assembly							
EXUP servo motor	Bolt	M6	2	6	0.6	4.3	
Crankcase	Bolt	M6	10	10	1.0	7.2	
Drive sprocket cover	Bolt	M6	2	12	1.2	8.7	
Drive sprocket cover	Bolt	M6	1	12	1.2	8.7	-15
Plate	Bolt	M6	2	12	1.2	8.7	-6



#### CHASSIS TIGHTENING TORQUES

Item		Tightening			Bomarke	
		Nm	m•kg	ft∙lb	Tiemarks	
Horn bracket and under bracket	M6	7	0.7	5.1		
Connecting rod assembly (YZF-R1LE)	M6	8	0.8	5.8		
Side cover and fuel tank	M5	4	0.4	2.9		
Front fork and stay (YZF-R1LE)	M5	6	0.6	4.3	-16	
Front fork and bracket (YZF-R1LE)	M5	6	0.6	4.3	-16	
Rear brake master cylinder and foot rest bracket	M6	13	1.3	9.4		
Front brake disc and front wheel (YZF-R1LE)	M6	23	2.3	17	-16	
Front wheel axle pinch bolt (YZF-R1LE)	M8	26	2.6	19	See NOTE	
Cap bolt (YZF-R1LE)		20	2.0	14		
Cap bolt and lock nut (YZF-R1LE)		25	2.5	18		
Damper rod assembly (YZF-R1LE)	—	48	4.8	35	-0	

**(4**) 3 1 2

#### NOTE: \_

- 1. Insert the front wheel axle from the right side and tighten it with the flange bolt from the left side to 91 Nm (9.1 m•kg, 65.8 ft•lb).
- In the order from the pinch bolt ② → pinch bolt ① → pinch bolt ②, tighten each bolt to 26 Nm (2.6 m•kg, 19 ft•lb) without performing temporary tightening.
- 3. Check that the end face of the axle head and the end face of the fork side are flushmounted. If they are out of alignment, make sure to fit them by adding the external force by hand or with a plastic hammer, etc.

If the end face of the axle is not parallel to the end face of the fork, align them so that one point of the axle circumference is positioned on the end face of the fork.

At this stage, it can be accepted if the end face of the axle becomes partially concave to the end face of the fork.

In the order from the pinch bolt ④ → pinch bolt ③ → pinch bolt ④, tighten each bolt to 26 Nm (2.6 m•kg, 19 ft•lb) without performing temporary tightening.



# LUBRICATION POINTS AND LUBRICANT TYPES ENGINE

Lubrication point	Lubricant
Valve lifter surfaces (intake and exhaust)	
Valve stem ends (intake and exhaust)	

# CHASSIS

Lubrication point	Lubricant
Pivot shaft	



### **LUBRICATION DIAGRAMS**

Main axle
 Oil delivery pipe
 Drive axle





#### EAS00035 CABLE ROUTING

- (1) Ground lead
- 2 Meter lead
- 3 Stay 1
- (4) Auxiliary light lead (right)
- (5) Headlight lead
- 6 Auxiliary light lead (left)
- (7) Console panel 1
- (8) Duct 1
- (9) Console panel 2
- (10) Duct 2
- (1) Headlight lead (right)
- (12) Headlight lead (left)

- light. (Either location of the right and left relays is acceptable.)
- B The lead should not stretch too much.
  - Direction of the ground terminal side.
- C Make sure to insert the coupler and boot to the stay 1 hole.
- D The speedometer lead should not be strained.
- E To the stay 1 hole

- A Insert to the rib of the head F Connect after passing over the upper side of the duct.
  - G Clamp the head light lead by wrapping and insert it to the intake air grill hole. (only at the right side.)
  - can be either top side or flip HDo not connect the wire to the coupler with the plug for options.
    - To the turn signal light
    - J To the wire harness
    - K Cut the tip of the clamp. Clamp the headlight lead to the positioning white tape section.





- L There should be no slack when clamping. Point the tip of the clamp (excessive part) to the front side of the vehicle. Fasten the head light lead with a clamp.
- M Feed a lead wire through the U shape cutout of the console panel.





- (1) Right handlebar switch lead
- 2 Clutch cable
- (3) Main switch lead
- (4) Left handlebar switch lead
- (5) Horn lead
- 6 Horn
- (7) Throttle cables
- (8) Brake hose
- (9) Throttle cable (return side)
- (1) Throttle cable (pull side)
- A Route the clutch cable so as to F Clamp the leads inside the front get along the front side of the main switch after passing it through the guide.
- through the guide wire.
- C Pass the left handlebar switch lead through the guide wire.
- D Point the tip of the band (excessive part) to the left side of the vehicle and cut the surplus section.
- E Clamp the section between 0 and 20 mm (0 and 0.79 in) from the split of the under bracket.

- fork of the vehicle. Point the exit of the horn lead to the left front fork side.
- B Pass the main switch lead G Route two throttle cables behind the brake hose, pass between the inside of the under bracket's upper side front fork and guide wire assembly, and then pass it through the clamp that is inserted to the cover 3 under the frame.





- H Contact the wire guide to the top face of the under bracket boss. The throttle cable should not be caught between the wire guide and under bracket. The throttle cable (pull side) should be positioned above the vehicle wen the wire guide is installed.
- Clamp should be positioned at the protector lower end of the brake hose and wrapped on the protector.
- J Cut the tip leaving 2 to 4mm  $0.08 \sim 0.16$  in).





- (1) Wire harness
- 2 Crankshaft position sensor lead
- (3) Heat protector
- (4) Right handlebar switch lead
- (5) Positioning guide
- 6 Rear brake light switch lead
- (7) Coolant reservoir tank
- (8) Speed sensor lead
- (9) Clutch cable
- (10) Radiator
- (11) Oil cooler outlet hose
- (12) Coolant reservoir tank drain hose
- (13) Breather pipe
- (14) Fuel tank drain hose
- (15) A.C. magneto lead
- (16) Wire harness

- (17) Throttle body lead
- A Clamp it after passing between the frame and radiator stay. Point the tip of the clamp (excessive part) to the front side of the vehicle. Fasten the right clamp.
- B To the wire harness
- C The clutch cable positioning guide should be above the upper end of the clamp. Fasten the clutch cable with a clamp. (Refer to M)
- D Position relation between the clamp and guide.

- E Clamp the clamp upper end along the line of lower end of the hose clamp assembly. Point the tip of the clamp (excessive part) to the front side of the vehicle. Clutch cable is what the clamp fastens.
- handlebar switch lead with a F The clutch cable doesn't project outside the water hose and the cylinder head in the box part in the figure.
  - G To the engine
  - H Clamp behind the bracket 3. Cut the tip of the clamp.





- solenoid lead and camshaft sensor lead should be connected above the ignition coil sub wire harness and it should not drop on the cylinder head cover behind the ignition coil.
- J Pass the right handlebar switch lead between the frame and heat protector.
- K Coolant reservoir tank drain hose should cross with the swingarm bracket. Route the coolant reservoir tank drain hose over the up side of the vehicle.
- The coupler for the air induction L Pass the rear brake light switch O Clamp the clutch cable so that it lead between the swingarm bracket and coolant reservoir tank.
  - M Release the tip of the clamp and install it to the clutch cable. Insert the clamp to the hole located on the right back side of the radiator.
    - Radiator fan motor lead should not be caught while inserting the clamp.
  - speed sensor lead under the N Push the clamp until it hits the radiator side stay. Radiator fan motor lead should not be caught.

- is within this specified clamp.
- P To the air filter
- Q Route the fuel tank drain hose over the canister stay and between the breather hose 2 and wire harness. On the front side of the canister stay, let though the bottom of the A.C.magneto lead and the wire harness.
- R Route by the upside of vehicle away from the canister stay.





- Heat protector
   Main switch lead
   Left handlebar switch lead
   EXUP servo motor lead
   Coolant reservoir tank drain hose
   Fuel tank drain hose
   Coolant outlet pipe
   Sidestand switch lead
   Oil level switch lead
   A.C.magneto lead
   Fuse box stay
   Water hose
   Stay 1
   Chain case cover
- A Clamp the leads so that they are positioned inner of the vehicle than the washer position after routing them between the frame and radiator stay. Align the clamp position with the taping sections of leads. Point the tip of the clamp (excessive part) to the down front side of the vehicle. What the clamp fastens at this stage are the handlebar switch and main switch leads.
- B Pass the main switch lead and left handlebar switch lead between the frame and the heat protector.

- C To the coolant reservoir tank
- D Fold back the clamp and secure it after passing the lead through the clamp.
- E To the EXUP servo motor
- F Pass the coolant reservoir tank drain hose and fuel tank drain hose through the clamp from the outer side of the water pump inlet pipe after routing it behind the water pump breather hose. The lengths of two hose ends are allowed to be random. Any direction of cut edges can be accepted. (Only for the fuel tank drain hose)





- G Clamp the fuel tank drain hose N Inner most section of the vehi- S Align the molded part of the fuel and fuel tank breather hose.
- H Route the lead by the inside of
- the water hose and water pipe. Route the lead by the inside of
- the water hose and water pipe. J There should be no exposure of
- displacement of the tube. K Route by the outside of vehicle
- away from the water hose. L Point the tip of the clamp (excessive part) to the down rear side of the vehicle. Fasten
- the wire harness with a clamp. M The outside of the vehicle.

- cle.
- O Can be routed in any order.
- P Route the water hose so that it is placed at the outermost position finally after routing other leads and hoses in the guide.
- bared conductors due to the Q Route the coolant reservoir tank drain hose so that it is routed at the innermost position to each hose and lead.
  - R Arrange so as not for each hose to cross in the part between "BB" from the section "AA" which is in the illustration.

- tank drain hose with the stay 1.
- T Routing of the fuel tank drain hose.
  - EXUP servo motor, oil level switch and sidestand switch leads are omitted in this drawing.





- (1) Heat protector
  - 2 Crankshaft position sensor lead
  - (3) Neutral switch lead
  - (4) Ground lead
- (5) Coolant reservoir tank
- 6 Battery positive lead
- (7) Starter relay
- (8) Turn signal relay
- (9) Main fuse
- (10) Lean angle sensor
- (1) Atmospheric pressure sensor
- (12) Tail /brake light lead
- (13) Rear fender
- (14) Seat lock cable
- (15) Anti safety alarm coupler
- (16) Starting circuit cut-off relay

(18) Starter motor lead (19) A.C.magneto lead

17 Battery negative lead

- 20 Oil level switch lead
- (2) Sidestand switch lead
- 2 Throttle body lead
- 23 Coolant reservoir tank drain hose
- 24) Fuel tank drain hose
- 25 Cover 7
- (26) Radiator fan motor lead (left)
- 27 Radiator fan motor lead (right)
- 28 Wire harness
- 29 Pipe 3
- 30 Frame
- (31) Coolant reservoir tank hose 32 Thermo stat assembly breather (47) Right handlebar switch lead
  - hose

(38) Speed sensor lead (39) Rear brake light switch lead

(33) Throttle body side cap

(35) Turn signal light lead 36 License plate light lead

40 Rear frame

34 Mud guard

(4) Swingarm bracket

37 Rear fender rib

- (42) Main fuse lead
  - (43) Starting circuit cut-off relay lead
- (4) Turn signal light relay lead
- (45) Starter relay lead
- (46) Main fuse lead (To the battery positive lead)





- A Pass the wire harness through G Point the tip of the clamp K Pass the water hose lower side the clamp inserted to the radiator stay.
- B To the headlight lead
- C Clamp the lead between three protrusions of the pipe (the first and second parts from the vehicle front). Point the tip of the clamp (excessive part) to the inside of the vehicle.

D To the vehicle right side diagram

- E To the engine
- F Clamp the lead between three protrusions of the pipe (the inside and outside of the vehicle).

- (excessive part) to the inside of the vehicle.
- HAII hoses and leads should be side above the heat protector.
- I To the starter motor
- J Fasten the wire harness, clank shaft position sensor lead, rear brake light switch lead and speed sensor lead with a clamp. Then, point the tip of the clamp (cut the tip of the clamp leaving 2 to 4 mm (0.08 to 0.16 in).) to the inside of the vehicle.
- of the thermostat, and between the ground lead and the neutral switch.
- routed over the vehicle's upper L Install the leads so that the engine ground lead is positioned lower and the battery negative lead to be upper. Install the protrusion of each lead to be above the vehicle.
  - M Route the crankshaft position sensor lead under the wire harness.
  - N To the fuel pump
  - O Clamp the wire harness winding in and insert it to the frame hole.





- P Pass the lead through inside of U Make sure to position the cou- W Point the tip of the clamp (surthe battery band. pler at the downmost position of plus section) to the rear side of
- Q Press on the tip of the clamp after passing the leads through it.
- R Insert the tail /brake light lead to the rear frame hole.
- S Insert the clamp from the vehicle front to the rear side and fasten each lead, coupler and onionhead to the fender rib, and then point the tip of the clamp (excessive part) to the upper side of the vehicle.
- T Hold down the clamp tips after passing each lead.

- Make sure to position the coupler at the downmost position of leads. However, the coupler should be set in the rear frame so that it is not caught by the seat bottom, cover and other components.
- V Point the tip of the clamp (excessive part) to the inside of the vehicle. Fasten the wire harness with a clamp.
- Point the tip of the clamp (surplus section) to the rear side of the vehicle. Fasten the starter relay lead, turn signal relay lead, main fuse lead, main fuse lead (from the battery positive lead) and starting circuit cut-off relay lead with a clamp.
- (excessive part) to the inside of X Route each lead upper side the the vehicle. Fasten the wire har-
  - Y Fasten the wire harness, battery negative lead and starter motor lead with a clamp. Point the tip of the clamp (excessive part) to the inside of the vehicle.





- Point the tip of the clamp (excessive part) to the down side of the vehicle. Fasten the wire harness, battery negative lead, A.C.magneto lead and starter motor lead with a clamp.
- AA To the speed sensor
- BB Insert the wire harness wrapping clamp to the hole of the frame.
- CC After passing the lead between the wire harness and starter motor leads, fastening by the clamp should be cancelled and route the lead under the idle remote controller.
- DD Fasten the wire harness, A.C.magneto lead, and throttle body lead with a clamp. Point the tip of the clamp (cut the tip of the clamp leaving 2 to 4 mm (0.08 to 0.16 in).) to the inside of the vehicle.
- EE To the air filter
- **FF** To the throttle body
- GG To install the cover 7, install so as to set each coupler in the cover. Make sure that each lead is not caught by the cover 7.
- [HH] Insert the wire harness wrapping clamp to the hole of the frame.
- II Make sure that the lead is fastened with the guide of the radiator stay.
- JJ To the right handlebar switch
- KK Battery negative lead should not run on the swingarm bracket.
- LL The hoses should not be located higher than the throttle body side cap over the up side of the vehicle.





- MM Do not place it beyond pipe 3 PP Route the leads in random in the direction to the external order. part of the vehicle.
- NN Route each lead higher than the frame plate, pass it to the inside of the vehicle from the hole. Leads should be routed in random order. Clamp can be inserted in any direction.
- OO Route each lead lower than the frame plate. Leads should be routed in random order. Clamp can be inserted in any direction.





- ① Fuel tank
- 2 O-ring
- ③ Fuel tank drain hose
- (4) Fuel tank breather hose
- 5 Clip
- 6 Air filter stay
- 7 Fuel hose 2
- 8 3 way connector
- 9 Pipe
- 10 Fuel tank bracket
- T Fuel hose clamp
- 12 Fuel hose 1
- 13 Fuel pump assembly

A Install the lip of O-ring facing Fuel piping connector attachupward. ment directions. (fuel pump

- B Install the part pointing the white paint part of the hose to the left side of the vehicle.
- C Any direction of the clip grip can 1. Insert the connector until the click sound is heard and check that the
- D Install the clip grip as specified \_\_\_\_\_ in the drawing.
- E Install the part pointing the white paint part of the hose to the left side of the vehicle.
- F Point the clip grip to the left side of the vehicle.

- Fuel piping connector attachment directions. (fuel pump side) Always use hands to connect/disconnect the connector without using tool.
- . Insert the connector until the click sound is heard and check that the connector does not come off. Make sure that no foreign matter is caught in the sealing section. (It is prohibited to wear the cotton work gloves or equivalent coverings.)
- G This part works as a dropout stopper.





 After Item 1 mentioned above is finished, check that the clamp is inserted from the down side, and (A), (B) and (C)-sections are perfectly equipped.





- for CAL
- 1 Clip
- 2 Clamp
- ③ Rivet
- (4) Roll over valve assembly
- 5 Balance pipe
- 6 Pipe 4
- (7) Canister hose
- (8) Canister assembly
- (9) Canister bracket
- (10) Frame
- (11) Canister stay
- (12) Pipe 2
- (13) Pipe 3

- A Insert the hose until it reaches F Install the part pointing the the R-bottom of the pipe.
- B Install the part pointing the side of the vehicle.
- C Point the clip grip to the upper side of the vehicle.
- D To the throttle body
- positioned in any direction.
- white paint mark to the left side of the vehicle.
- white paint mark to the front G Install the part pointing the yellow paint mark to the left side of the vehicle.
  - H Point the clip grip to the down side of the vehicle.
- E The knob of the clip can be I Insert the hose so that its tip of the nipple does not protrude.





EAS00036

# PERIODIC CHECKS AND ADJUSTMENTS

#### INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale, All service technicians should be familiar with this entire chapter.

# PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

No.		ITEM	ROUTINE	INITIAL	INITIAL ODOMETER READINGS					
				600 mi (1,000 km) or 1 month	4,000 mi (7,000 km) or 6 months	8,000 mi (13,000 km) or 12 months	12,000 mi (19,000 km) or 18 months	16,000 mi (25,000 km) or 24 months	20,000 mi (31,000 km) or 30 months	
1	*	Fuel line	<ul><li>Check fuel hoses for cracks or damage.</li><li>Replace if necessary.</li></ul>		√	$\checkmark$	V	$\checkmark$	V	
2	*	Spark plugs	<ul> <li>Check condition.</li> <li>Adjust gap and clean.</li> <li>Replace every 8,000 mi (13,000 km) or 12 months.</li> </ul>		$\checkmark$	Replace.	$\checkmark$	Replace.	$\checkmark$	
3	*	Valve clearance	Check and adjust valve clearance when engine is cold.	Every 26,600 mi (42,000 km)						
4	*	Crankcase breather system	<ul><li>Check breather hose for cracks or damage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
5	*	Fuel injection	<ul> <li>Check and adjust engine idle speed and syn- chronization.</li> </ul>	$\checkmark$	V	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
6	*	Exhaust system	<ul> <li>Check for leakage.</li> <li>Tighten if necessary.</li> <li>Replace gasket(s) if necessary.</li> </ul>		V	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
7	*	Evaporative emission control system (For California only)	<ul><li>Check control system for damage.</li><li>Replace if necessary.</li></ul>				$\checkmark$		$\checkmark$	
8	*	Air induction system	<ul> <li>Check the air cut-off valve, reed valve, and hose for damage.</li> <li>Replace any damaged parts if necessary.</li> </ul>				$\checkmark$		$\checkmark$	

# **GENERAL MAINTENANCE AND LUBRICATION CHART**

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
				600 mi (1,000 km) or 1 month	4,000 mi (7,000 km) or 6 months	8,000 mi (13,000 km) or 12 months	12,000 mi (19,000 km) or 18 months	16,000 mi (25,000 km) or 24 months	20,000 mi (31,000 km) or 30 months	
1	*	Air filter element	<ul><li>Check condition and damage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
2	*	Clutch	<ul><li>Check operation.</li><li>Adjust or replace cable.</li></ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
3	*	Front brake	<ul> <li>Check operation, fluid level, and for fluid leak- age.</li> <li>Replace brake pads if necessary.</li> </ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
4	*	Rear brake	<ul> <li>Check operation, fluid level, and for fluid leak- age.</li> <li>Replace brake pads if necessary.</li> </ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
5	*	Brake hoses	Check for cracks or damage.		$\checkmark$	$\checkmark$	$\checkmark$	V	V	
5			Replace.	Every 4 years						
6	*	Wheels	<ul><li>Check runout and for damage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
7	*	Tires	<ul> <li>Check tread depth and for damage.</li> <li>Replace if necessary.</li> <li>Check air pressure.</li> <li>Correct if necessary.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
8	*	Wheel bearings	<ul><li>Check bearings for smooth operation.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	

# GENERAL MAINTENANCE AND LUBRICATION CHART



				INITIAL		ODC	DMETER REA	DINGS	
No.		ITEM	ROUTINE	600 mi (1,000 km)	4,000 mi (7,000 km)	8,000 mi (13,000 km)	12,000 mi (19,000 km)	16,000 mi (25,000 km)	20,000 mi (31,000 km)
				1 month	6 months	12 months	18 months	24 months	30 months
9	*	Swingarm pivot bearings	<ul> <li>Check bearing assemblies for looseness.</li> <li>Moderately repack with lithium-soap-based grease.</li> </ul>			$\checkmark$		Repack.	
10		Drive chain	<ul> <li>Check chain slack'alignment and condition.</li> <li>Adjust and lubricate chain with a special O-ring chain lubricant thoroughly.</li> </ul>	Every 500 mi (800 km) and after washing the vehicle or riding in the ra					n the rain
11	*	Steering bearings	<ul> <li>Check bearing assemblies for looseness.</li> <li>Moderately repack with lithium-soap-based grease every 16,000 mi (2,5000 km) or 24 months.</li> </ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	Repack.	$\checkmark$
12	*	Steering damper	<ul> <li>Check operation and for oil leakage.</li> </ul>			V	V	V	√
13	*	Chassis fasteners	<ul><li>Check all chassis fitting and fasteners.</li><li>Correct if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
14		Brake and clutch lever pivot shafts	<ul> <li>Apply lithium-soap-based grease (all-purpose grease) lightly.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
15		Sidestand pivot	<ul> <li>Check operation.</li> <li>Apply lithium-soap-based grease (all-purpose grease) lightly.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
16	*	Sidestand switch	Check operation and replace if necessary.		$\checkmark$	$\checkmark$	$\checkmark$	V	$\checkmark$
17	*	Front fork	<ul><li>Check operation and for oil leakage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
18	*	Shock absorber assembly	<ul><li>Check operation and for oil leakage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
19	*	Rear suspension link pivots	<ul><li>Check operation.</li><li>Correct if necessary.</li></ul>			$\checkmark$		$\checkmark$	
20		Engine oil	Change (warm engine before draining.)			$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
21	*	Engine oil filter car- tridge	Replace.	$\checkmark$		$\checkmark$		$\checkmark$	
22	*	Cooling system	<ul><li>Check hoses for cracks or damage.</li><li>Replace if necessary.</li></ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
22			Change with ethylene glycol antifreeze coolant every 24 months.					Change.	
23	*	EXUP system	<ul> <li>Check operation, cable free play and pulley position.</li> </ul>	√ Every 12,000 mi (19,000 km)					
24	*	Front and rear brake switches	Check operation.	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
25	*	Control cables	Apply Yamaha chain and cable lube or engine oil SAE 10W-30 thoroughly.	$\checkmark$	V	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
26	*	Throttle grip housing and cable	<ul> <li>Check operation and free play</li> <li>Adjust the throttle cable free play if necessary.</li> <li>Lubricate the throttle grip housing and cable.</li> </ul>		V	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
27	*	Lights, signals and switches	<ul><li>Check operation.</li><li>Adjust headlight beam.</li></ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$

\* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

#### NOTE:

From 24,000 mi (37,000 km) or 36 months, repeat the maintenance intervals starting from 8,000 mi (13,000 km) or 12 months.

#### NOTE: \_

- Air filter
- This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
- The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
- After disassembling the brake master cylinders and calipers, always change the fluid. Regularly check the brake fluid levels and fill the reservoirs as required.
- Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
- Replace the brake hoses every four years and if cracked or damaged.


# CHASSIS

## ADJUSTING THE FRONT FORK LEGS

(YZF-R1LE)

The following procedure applies to both of the front fork legs.

## 

- Always adjust both front fork legs evenly. Uneven adjustment can result in poor handling and loss of stability.
- Securely support the vehicle so that there is no danger of it falling over.

#### Spring preload

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- spring preload

#### \*\*\*\*

a. Turn the adjusting bolt ① in direction ③ or ⑤.

#### NOTE: \_\_\_\_

Be sure to align the alignment mark on the adjusting bolt with the alignment mark on the front fork cap.

Direction (a)	Spring preload is increased (suspension is harder).
Direction (b)	Spring preload is decreased (suspension is softer).

**Adjusting positions** 

Minimum: 11 turns in direction (b)\* Maximum: 2 turns in direction (a)\* \*from the standard position





#### NOTE: \_

To find the standard position, turn the adjusting bolt in direction (a) until it stop.

 If the alignment mark on the adjusting bolt is positioned past the alignment mark on the front fork cap, turn the adjusting bolt in direction (b) until the alignment marks match.

Turn the adjusting bolt 3 complete turns in direction (b), and be sure the alignment mark match.

This is the standard position.

 If the alignment mark on the adjusting bolt is positioned before the alignment mark on the front fork cap, turn the adjusting bolt in direction (b) until the alignment marks match.

Turn the adjusting bolt 2 complete turns in direction (b), and be sure the alignment mark match.

This is the standard position.

#### 

#### **Rebound damping**

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
  - rebound damping

\*\*\*\*

a. Turn the adjusting screw (1) in direction (a) or (b).

Direction (a)	Rebound damping is increased (suspension is harder).
Direction (b)	Rebound damping is decreased (suspension is softer).

Adjusting positions Minimum: 17 clicks in direction (b)\* Standard: 12 clicks in direction (b) \* Maximum: 1 clicks in direction (b) \*

\* with the adjusting screw fully turned-in direction (a)





#### **Compression damping**

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- compression damping
- a. Turn the adjusting screw ① in direction ⓐ or ⓑ.

Direction (a)	Compression damping is increased (suspension is harder).
Direction (b)	Compression damping is decreased (suspension is softer).

Adjusting positions

- Minimum:20 clicks in direction  $b^*$
- Standard: 12 clicks in direction  $\textcircled{b}^*$
- Maximum: 1 clicks in direction  $(\vec{b})^*$
- $^{\ast}$  with the adjusting screw fully turned-in direction (a)





ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY (YZF-R1LE)

## A WARNING

Securely support the vehicle so that there is no danger of it falling over.

Spring preload

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- spring preload
- \*\*\*\*\*
- a. Turn the adjusting knob (1) in direction (a) or (b).

Direction (a)	Spring preload is increased (suspension is harder).
Direction (b)	Spring preload is decreased (suspension is softer).

Adjusting positions Minimum: 0 turns in direction (a)\* Standard: 6 turns in direction (a)\* Maximum: 20 turns in direction (a)\* \*with the adjusting knob fully turned-in direction (b)

\_\_\_\_

**Rebound damping** 

**CAUTION:** 

Never go beyond the maximum or minimum adjustment positions.



## ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY





- 1. Adjust:
- rebound damping
- \*\*\*\*\*
- a. Turn the adjusting screw (1) in direction (a) or (b).

Direction (a)	Rebound damping is increased (suspension is harder).
Direction (b)	Rebound damping is decreased (suspension is softer).

Adjusting positions Minimum: 18 clicks in direction (b) \* Standard: 14 clicks in direction (b)\* Maximum: 1 clicks in direction (b)\* \* with the adjusting screw fully turned-in direction (a)

Compression damping (fast compression damping)

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
  - fast compression damping

\*\*\*\*

a. Turn the adjusting bolt ① in direction ③ or ⑤.

Direction (a)	Compression damping is increased (suspension is harder).
Direction (b)	Compression damping is decreased (suspension is softer).

Adjusting positions Minimum: 42 clicks in direction (b) \* Standard: 30 clicks in direction (b)\* Maximum: 1 clicks in direction (b)\*

 $^{\ast}$  with the adjusting screw fully turned-in direction (a)





Compression damping (slow compression damping)

#### **CAUTION:**

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
  - slow compression damping
- a. Turn the adjusting screw ① in direction ⓐ or ⓑ.

Direction (a)	Compression damping is increased (suspension is harder).	
Direction (b)	Compression damping is decreased (suspension is softer).	

Adjusting positions Minimum: 17 clicks in direction (b) \* Standard: 10 clicks in direction (b)\* Maximum: 1 clicks in direction (b)\* \* with the adjusting screw fully turned-in direction (a)





EAS00514

CHASSIS

## FRONT WHEEL AND BRAKE DISCS



Order	Job/Part	Q'ty	Remarks
	Removing the front wheel and brake		Remove the parts in the order listed.
	aiscs		NOTE:
			Place the vehicle on a suitable stand so that the front wheel is elevated.
1	Brake hose holder (left and right)	2	
2	Front brake caliper (left and right)	2	
3	Front wheel axle pinch bolt	4	
4	Front wheel axle bolt	1	
5	Front wheel axle	1	
6	Collar (left and right)	2	
7	Front wheel	1	
8	Front brake disc (left and right)	2	
			For installation, reverse the removal procedure.



## REAR WHEEL AND BRAKE DISCS REAR BRAKE DISC AND REAR WHEEL SPROCKET



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake disc and rear wheel sprocket		Remove the parts in the order listed.
1	Rear brake disc	1	
2	Rear wheel sprocket	1	
3	Collar	2	
4	Oil seal	1	
5	Bearing	1	
6	Rear wheel drive hub	1	
7	Rear wheel drive hub damper	5	
8	Rear wheel	1	
			For installation, reverse the disassembly procedure.





Order	Job/Part	Q'ty	Remarks
	Disassembling the rear wheel		Disassemble the parts in the order listed.
1	Collar	1	
2	Bearing	1	
3	Spacer	1	
4	Oil seal	1	
(5)	Bearing	1	
			For assembly, reverse the disassembly procedure.

**FRONT FORK** 



## FRONT FORK FRONT FORK LEGS



Order	Job/Part	Q'ty	Remarks
	Disassembling the front fork legs		Disassemble the parts in the order listed.
			NOTE:
			The following the procedure applies to both of the front fork legs.
(1)	Fork stay	1	
Ž	Fork bracket	1	
3	Cap bolt	1	
4	O-ring	1	
(5)	Damper adjusting rod	1	
6	Nut	1	
$\bigcirc$	Spring seat (upper)	1	
8	Fork spring	1	
9	Clip	1	
10	Spacer	1	

FRONT FORK





Order	Job/Part	Q'ty	Remarks
(11)	Spring guide	1	
12	Spring seat	1	
13	Dust seal	1	
(14)	Oil seal clip	1	
15	Oil seal	1	
16	Washer	1	
17	Damper rod assembly	1	
18	Inner tube	1	
19	Outer tube	1	
			For assembly, reverse the disassembly procedure.





## DISASSEMBLING THE FRONT FORK LEGS (YZF-R1LE)

The following procedure applies to both of the front fork legs.

- 1. Remove:
  - fork stay
  - fork bracket
  - cap bolt ① (from the damper adjusting rod)
- a. Press down on the spacer with the fork spring compressor ④.
- b. Install the spanner (5) between the nut (3) and the spring seat (upper) (2).



#### Fork spring compressor 90890-01441, YM-01441

- c. Loosen the nut.
- d. Remove the cap bolt.
- e. Remove the spanner and fork spring compressor.

## A WARNING

The fork spring is compressed.





- 2. Remove
  - nut
  - spring seat (upper)
  - fork spring
  - clip (1)
  - spacer
  - spring guide
- 3. Drain:
- fork oil

#### NOTE: \_

Stroke the damper rod (1) several times while draining the fork oil.









#### 4. Remove:

- dust seal
- oil seal clip ①

**FRONT FORK** 

- oil sealwasher
  - (with a flat-head screwdriver)

#### **CAUTION:**

#### Do not scratch the inner tube.

- 5. Remove:
  - spring seat (1)

#### NOTE: \_\_\_\_

Use a wire or the like and bend the end in Lletter shape for about 10 mm (0.39 in) and hook this part to the spring seat end and pull out the spring seat.

- 6. Remove:
  - damper rod assembly

#### NOTE: \_\_\_\_

While holding the inner tube with the damper rod holder (1), loosen the damper rod assembly.

Damper rod holder 90890–01504

41









# 

## CHECKING THE FRONT FORK LEGS (YZF-R1LE)

The following procedure applies to both of the front fork legs.

- 1. Check:
  - inner tube ①
  - outer tube (2)
  - Bends/damage/scratches  $\rightarrow$  Replace.

## 

Do not attempt to straighten a bent inner tube as this may dangerously weaken it.

- 2. Measure:
  - spring free length ⓐ
    Out of specification → Replace.



Spring free length 260 mm (10.24 in) <Limit> : 254.8 mm (10.03 in)

- 3. Check:
- damper rod ①
  Damage/wear → Replace.
  Obstruction → Blow out all of the oil passages with compressed air.
- damper rod adjusting rod Bends/damage  $\rightarrow$  Replace.

## CAUTION:

- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.
- 4. Check:
  - cap bolt ①
  - Damage  $\rightarrow$  Replace.
  - cap bolt O-ring New



## ASSEMBLING THE FRONT FORK LEGS (YZF-R1LE)

The following procedure applies to both of the front fork legs.

## 

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

#### NOTE: \_\_\_\_

- When assembling the front fork leg, be sure to replace the following parts:
- oil seal clip
- oil seal
- dust seal
- Before assembling the front fork leg, make sure all of the components are clean.
- 1. Install:
  - inner tube (1)
  - damper rod assembly (2)





#### 2. Tighten:

damper rod assembly

▲ 48 Nm (4.8 m•kg, 35 ft•lb) LOCTITE<sup>®</sup>

#### NOTE: \_

While holding the inner tube with the damper rod holder (2), tighten the damper rod assembly.



- 3. Lubricate:
  - inner tube's outer surface



Recommended lubricant Suspension oil "Ohlins R&T 43" (ACC-RT43F-00-00)







- 4. Install:
- dust seal ①
- oil seal clip 2
- oil seal ③
- washer  $\overline{4}$

## CAUTION:

Make sure the numbered side of the oil seal faces up.

#### NOTE: \_

- Before installing the oil seal, lubricate its lips with lithium-soap-based grease.
- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag to protect the oil seal during installation.





- 5. Install:
  - Oil seal ① (with the fork seal driver ②)



Fork seal driver 90890-01442, YM-01442

6. Install:

• oil seal clip (1)

#### NOTE: \_

Adjust the oil seal clip so that it fits into the outer tube's groove.

CHAS of 50





- 7. Install:
  - dust seal ①
     (with the fork seal driver weight ②)

**FRONT FORK** 



Fork seal driver 90890-01442, YM-01442

- 8. Install:
  - rod puller (1)
  - rod puller attachment (2) (onto the damper rod (3))



Rod puller 90890-01437, YM-A8703 Rod puller attachment 90890-01435, YM-A8703

- 9. Fill:
- front fork leg (with the specified amount of the recommended fork oil)



Quantity (each front fork leg) 0.43 L (0.38 Imp qt, 0.45 US qt) Recommended oil Suspension oil "Ohlins R&T 43" (ACC-RT43F-00-00)

Front fork leg oil level (from the top of the outer tube, with the outer tube fully compressed and without the fork spring) 145 mm (5.71 in)

#### NOTE: \_\_\_\_

- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.







10.Install:

- spring seat (1)
- spring guide 2
- spacer ③
- clip (4)
- fork spring (5)
- spring seat (upper) 6

**FRONT FORK** 

- nut (7)
- damper adjusting rod (8)
- cap bolt (9)
- fork bracket
- fork stay
- a. Install the spring seat, spring guide, spacer and circlip.
- b. Install the fork spring, spring seat (upper) and nut.
- c. Press down on the spring seat with the fork spring compressor ①.
- d. Pull up the rod puller and install the nut (2).



#### Fork spring compressor 90890-01441, YM-01441

- e. Remove the rod puller and adapter.
- f. Install the nut (1) and position it as specified (b).



#### Distance (b) More than 25 mm (0.98 in)

g. Install the damper adjusting rod and cap bolt, and then finger tighten the cap bolt until it stop.

#### NOTE: \_

Install the cap bolt with rebound damping screw fully loosened.

h. Hold the cap bolt and tighten the nut to specification.

# N.

Nut 25 Nm (2.5 m•kg, 18 ft•lb)

i. Remove the fork spring compressor.

## A WARNING

- The fork spring is compressed.
- Always use a new cap bolt O-ring.



## REAR SHOCK ABSORBER ASSEMBLY



Order	Job/Part	Q'ty	Remarks
	Removing the rear shock absorber		Remove the parts in the order listed.
	assembly		
	Rider seat and passenger seat		Refer to "SEATS" in chapter 3.
	Fuel tank		Refer to "FUEL TANK" in chapter 3.
	Bottom cowling and rear cowling (upper)		Refer to "COWLINGS" in chapter 3.
	Protector, muffler, catalyst pipe assembly and EXUP servo motor		Refer to "EXHAUST PIPE" in chapter 5.
1	Self-locking nut/bolt	1/1	
2	Self-locking nut/bolt	1/1	
3	Self-locking nut/bolt	1/1	
4	Self-locking nut	1	
5	Rear shock absorber assembly	1	
6	Oil seal/bearing/collar	4/2/2	
7	Collar/self-locking nut/bolt	1/1/1	
8	Connecting rod	1	
9	Oil seal/bearing/collar	4/2/2	





Order	Job/Part	Q'ty	Remarks
10	Relay arm	1	For installation, reverse the removal procedure.

FASOORO



#### REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

(YZF-R1LE)

1. Stand the vehicle on a level surface.

## 

Becurely support the vehicle so that there is no danger of it falling over.

#### NOTE: \_\_\_\_

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
  - rider seat and passengerseat Refer to "SEATS" in chapter 3.
  - fuel tank Refer to "FUEL TANK" in chapter 3.
  - bottom cowling
  - rear cowling (upper)
  - Refer to "COWLINGS" in chapter 3.
  - protector
  - muffler
  - catalyst pipe assembly
  - EXUP servo motor Refer to "EXHAUST PIPE" in chapter 5.





- 3. Remove:
  - connecting rod front bolt ①
  - rear shock absorber assembly lower bolt (2)
  - relay arm-to-swingarm bolt ③

#### NOTE: \_\_\_\_

While removing the rear shock absorber assembly lower bolt, hold the swingarm so that it does not drop down.

- 4. Remove:
  - rear shock absorber assembly upper nut ①
  - rear shock absorber assembly

#### NOTE: \_

Raise the swingarm and then remove the rear shock absorber assembly from between the swingarm.

FASOOR



## INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

(YZF-R1LE)

- 1. Lubricate:
  - spacers
  - bearings

Recommended lubricant Lithium – soap-based grease

- 2. Check:
- connecting rod assembly Refer to "CHECKING THE CONNECTING ROD ASSEMBLY"
- 3. Install:
  - rear shock absorber assembly

#### NOTE: \_

• When installing the rear shock absorber assembly, lift up the swingarm.

• Install the connecting rod front bolt from the left.

#### 4. Tighten:

- rear shock absorber assembly upper nut
- rear shock absorber assembly lower nut
  - 🔌 44 Nm (4.4 m•kg, 32 ft•lb)
- relay arm-to swingarm nut
- connecting rod front nut
  [24 Nm (4.4 m•kg, 32 ft•lb)]
- 5. Install:
  - EXUP servo motor
  - · catalyst pipe assembly
  - muffler
  - protector
    Defor to "EXHAUST PIPE" in above
    - Refer to "EXHAUST PIPE" in chapter 5.
  - rear cowling (upper)
  - bottom cowling Refer to "COWLINGS" in chapter 3.
  - fuel tank
    - Refer to "FUEL TANK" in chapter 3.
  - rider seat and passenger seat Refer to "SEATS" in chapter 3.

EAS00703



#### SWINGARM AND DRIVE CHAIN REMOVING THE SWINGARM

(YZF-R1LE)

1. Stand the vehicle on a level surface.

## 

Securely support the vehicle so that there is no danger of it falling over.

#### NOTE: \_

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
  - rear wheel
  - rear shock absorber Refer to "REMOVING THE REAR WHEEL" and "REMOVING THE REAR SHOCK ABSORBER ASSEMBLY"
  - coolant reservoir tank

#### NOTE: \_

When removing the rear shock absorber assembly lower bolt, hold the swingarm so that it does not drop down.

- 3. Measure:
  - swingarm side play
  - swingarm vertical movement
- a. Measure the tightening torque of the pivot shaft nut.



Pivot shaft nut 105 Nm (10.5 m•kg, 76 ft•lb)

- b. Measure the swingarm side play A by moving the swingarm from side to side.
- c. If the swingarm side play is out of specification, check the spacers, bearings, washers, and dust covers.



Swingarm side play (at the end of the swingarm) 1.0 mm (0.04 in)

d. Check the swingarm vertical movement B by moving the swingarm up and down.
 If swingarm vertical movement is not smooth or if there is binding, check the spacers, bearings, washers, and dust covers.



## SWINGARM AND DRIVE CHAIN

FAS00707







#### **CHECKING THE SWINGARM**

#### (YZF-R1LE)

- 1. Check:
  - swingarm Bends/cracks/damage  $\rightarrow$  Replace.
- 2. Check:

• pivot shaft Roll the pivot shaft on a flat surface. Bends  $\rightarrow$  Replace.

## **WARNING**

Do not attempt to straighten a bent pivot shaft.

- 3. Wash:
  - pivot shaft
  - dust covers
  - spacer
  - washers
  - bearings



**Recommended cleaning solvent** 

- dust covers (1)
- spacer (2)
- Damage/wear  $\rightarrow$  Replace. • bearings ③ Damage/pitting  $\rightarrow$  Replace.
- 5. Check:
  - connecting rod assembly (4) Refer to "CHECKING THE CONNECTING ROD ASSEMBLY"
  - relay arm (5) Damage/wear  $\rightarrow$  Replace.
- 6. Check:
  - bearings (6)
  - oil seals (7) Damage/pitting  $\rightarrow$  Replace.
- 7. Check:
- collars (8) Damage/scratches  $\rightarrow$  Replace.







#### CHECKING THE CONNECTING ROD ASSEMBLY

#### 1. Check:

- connecting rod assembly Bends/damage → Replace the connecting rod assembly
- oil seal
- Damage/wear  $\rightarrow$  Replace
- bearing
- Damage/wear  $\rightarrow$  Replace
- 2. Measure:
- connecting rod assembly length (a).
  Out of specification → Adjust



Connecting rod assembly length STD: 206 mm (8.11 in) Adjust length 201 ~ 206 mm (7.91 ~ 8.11 in)

#### NOTE:

When the connecting rod assembly is removed, disassembled and replaced, set it to 206 mm (8.11 in).

#### \*\*\*\*\*\*

- a. Tighten the connecting rod 1 (1) and connecting rod 2 (2) fully to the connecting rod arm (3).
- b. Rotate the connecting rod 1 (1) (within one rotation) so that the bearing is parallel. At this time, align the direction of bolt.
- c. Rotate the connecting rod arm ③ to adjust the connecting rod assembly length to 206 mm (8.11 in).
- d. Tighten the connecting rod bolt temporarily.
- e. Attach the connecting rod assembly to the vehicle and tighten the connecting rod bolt securely.











## CHECKING THE DRIVE CHAIN

- 1. Measure:
  - Measure the dimension between 15-links on the inner side (a) and outer side (b) of the roller and calculate the dimension between pin centers.
  - Dimension © between pin centers = (Inner dimension ⓐ + Outer dimension ⓑ)/2
- 15-link section ⓒ of the drive chain Out of specification → Replace the drive chain, front drive sprocket and rear drive sprocket as a set.



15-link drive chain section limit (maximum) 239.3 mm (9.42 in)

#### NOTE: \_\_\_\_

- While measuring the 15-link section, push down on the drive chain to increase its tension.
- Perform this measurement at two or three different places.





- 2. Check:
  - drive chain Stiffness  $\rightarrow$  Clean and lubricate or replace.

- 3. Clean:
- drive chain
- a. Wipe the drive chain with a clean cloth.
- b. Put the drive chain in kerosene and remove any remaining dirt.
- c. Remove the drive chain from the kerosene and completely dry it.





## **CAUTION:**

This vehicle has a drive chain with small rubber O-rings ① between the drive chain side plates. Never use high-pressure water or air, steam, gasoline, certain solvents (e.g., benzine), or a coarse brush to clean the drive chain. High-pressure methods could force dirt or water into the drive chain's internals, and solvents will deteriorate the O-rings. A coarse brush can also damage the O-rings. Therefore, use only kerosine to clean the drive chain.

# 

- 4. Check:
  - O-rings ①
    - Damage  $\rightarrow$  Replace the drive chain.
  - drive chain rollers ②
    Damage/wear → Replace the drive chain.
  - drive chain side plates ③
    Damage/wear → Replace the drive chain.
    Cracks → Replace the drive chain and make sure that the battery breather hose is properly routed away from the drive chain and below the swingarm.
- 5. Lubricate:
  - drive chain

Recommended lubricant Engine oil or chain lubricant suitable for O-ring chains



- 6. Check:
  - drive sprocket
  - rear wheel sprocket
  - More than 1/4 tooth (a) wear  $\rightarrow$  Replace the drive chain sprockets as a set.
  - Bent teeth  $\rightarrow$  Replace the drive chain sprockets as a set.
- (b) Correct
- 1 Drive chain roller
- 2 Drive chain sprocket



#### ENGINE



Order	Job/Part	Q'ty	Remarks
	Removing the engine		Remove the parts in the order listed.
			NOTE:
			Place a suitable stand under the frame
			and engine.
1	Bight front engine mounting bolt	1	
2	Engine mount collar (inside) (YZE-B1)	1	
_	Engine mount collar (inside, outside) (YZF-R1LE)	2	
3	Engine mount collar (outside) (YZF-R1)	1	
	Engine mount collar (center) (YZF-R1LE)	1	
4	Left front engine mounting bolt	1	
5	Lower self locking nut	1	
6	Lower engine mounting bolt	1	
7	Upper self locking nut	1	





Order	Job/Part	Q'ty	Remarks
8	Upper engine mounting bolt	1	
9	Engine mounting adjust bolt	2	NOTE:
10	Engine	1	Use the pivot shaft wrench and adapter to loosen the engine mounting adjust bolts.
			For installation, reverse the removal procedure.



#### INSTALLING THE ENGINE

- 1. Install:
  - engine mounting adjust bolts (temporary tighten)
- 2. Install:
  - engine
- 3. Install:
  - lower engine mounting bolt (1)
  - upper engine mounting bolt (2)
  - self locking nuts

#### NOTE: \_

Lubricate the lower and upper engine mounting bolts threads with lithium-soap-based grease.

- 4. Install:
  - left front engine mount bolt ① (temporary tighten)

- 5. Install:
  - engine mount collar (inside)
  - engine mount collar (outside) (2)
  - right front engine mount bolt ③ (temporary tighten)
  - engine mount collar (inside, outside) ④
  - engine mount collar (center) (5)
- AYZF-R1
- BYZF-R1LE
- 6. Tighten:
  - engine mounting adjust bolts

🔀 7 Nm (0.7 m•kg, 5.1 ft•lb)

#### NOTE: \_\_\_\_

Use the pivot shaft wrench (1) and pivot shaft wrench adapter (2) to tighten the engine mounting adjust bolts.





















Pivot 908 Pivot 908

Pivot shaft wrench 90890-01471, YM-01471 Pivot shaft wrench adapter 90890-01476

- 7. Tighten:
  - upper self-locking nut ①
  - lower self-locking nut (2)

#### 🔀 51 Nm (5.1 m•kg, 37 ft•lb)

#### NOTE:

First tighten the lower self-locking nut, and then tighten the upper self-locking nut.

- 8. Tighten:
- left front engine mounting bolt ①
  [
  x] 45 Nm (4.5 m•kg, 33 ft•lb)

- 9. Tighten:
- right front engine mounting bolt ①
  [
  X, 45 Nm (4.5 m•kg, 33 ft•lb)]



#### CAMSHAFTS



Order	Job/Part	Q'ty	Remarks
	Removing the camshafts		Remove the parts in the order listed.
	Pickup rotor cover		Refer to "CRANKSHAFT POSITION
			SENSOR AND PICKUP ROTOR".
1	Camshaft sprocket bolt	4	Loosen.
2	Timing chain tensioner	1	
3	Timing chain tensioner gasket	1	
4	Intake camshaft cap	3	
5	Dowel pin	6	
6	Exhaust camshaft cap	3	
7	Dowel pin	6	
			Refer to "REMOVING THE
			CAMSHAFTS".
8	Intake camshaft	1	
9	Exhaust camshaft	1	
10	Camshaft sprocket	2	
			For installation, reverse the removal procedure.





Order	Job/Part	Q'ty	Remarks
	Removing the clutch cover		Remove the parts in the order listed.
	Right side cowling		
	Right frame side cover		
	Right frame side panel		
	Bottom cowling		
	Engine oil		Drain.
			Refer to "CHANGING THE ENGINE OIL"
			in chapter 3.
1	Cover	1	
2	Clutch cable	1	Disconnect.
3	Clutch cover	1	
4	Clutch cover gasket	1	
5	Dowel pin	2	
6	Oil filler cap	1	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Removing the clutch		Remove the parts in the order listed.
1	Compression spring	6	
2	Pressure plate	1	
3	Pull rod	1	
4	Bearing	1	
5	Friction plate 1	1	
6	Clutch plate 1	7	
7	Friction plate 2	7	
8	Wire clip	1	
9	Clutch plate 2	1	
10	Friction plate 3	1	
11	Clutch damper spring	1	
12	Clutch damper spring seat	1	

CLUTCH





Order	Job/Part	Q'ty	Remarks
13	Clutch boss nut	1	
14	Washer	1	
15	Thrust plate 1	1	
16	Clutch boss	1	
17	Thrust plate 2	1	
18	Clutch housing	1	
19	Bearing	1	
			For installation, reverse the removal procedure.

CLUTCH





Order	Job/Part	Q'ty	Remarks
	Removing the clutch		Remove the parts in the order listed.
1	Compression spring	6	
2	Pressure plate 1	1	
3	Pull rod	1	
4	Bearing	1	
5	Friction plate 1	1	
6	Clutch plate 1	1	
7	Friction plate 2	7	
8	Clutch plate 2	1	
9	Clutch plate 3	6	
10	Friction plate 3	1	
11	Clutch damper spring	1	
12	Clutch damper spring seat	1	
13	Clutch boss nut	1	
CLUTCH





Order	Job/Part	Q'ty	Remarks
14	Spring	3	
15	Clutch boss	1	
16	Pressure plate 2	1	
17	Conical spring washer	1	
18	Thrust plate 2	1	
19	Clutch housing	1	
20	Bearing	1	
			For installation, reverse the removal
			procedure.













#### 

(YZF-R1LE)

- 1. Remove:
- clutch cover ①
- gasket

#### NOTE: \_

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern.

After all of the bolts are fully loosened, remove them.

- 2. Remove:
  - $\bullet$  compression spring bolts (1)
  - compression springs
  - pressure plate (2)
  - pull rod ③
- 3. Remove:
- friction plate 1 (1)

- 4. Remove:
  - clutch plate 1 (1)
  - friction plate 2
  - clutch plate 2
  - clutch plate 3
  - friction plate 3
  - clutch damper spring
  - clutch damper spring seat
- 5. Straighten the clutch boss nut rib (1).





6. Loosen:

• clutch boss nut ①

#### NOTE: \_

While holding the clutch boss ② with the universal clutch holder ③, loosen the clutch boss nut.



- 7. Remove:
  - clutch boss nut
  - springs
- clutch boss
- pressure plate 2
- conical spring washer
- thrust plate 2

EAS00280

# CHECKING THE FRICTION PLATES

#### (YZF-R1LE)

The following procedure applies to all of the friction plates.

- 1. Check:
  - friction plate

Damage/wear  $\rightarrow$  Replace the friction plates as a set.

2. Measure:

friction plate thickness
 Out of specification → Replace the friction plates as a set.

#### NOTE: \_

Measure the friction plate at four places.







#### 

#### (YZF-R1LE)

The following procedure applies to all of the clutch plates.

- 1. Check:
  - clutch plate

Damage  $\rightarrow$  Replace the clutch plates as a set.

- 2. Measure:
  - clutch plate warpage

(with a surface plate and thickness gauge 1)

Out of specification  $\rightarrow$  Replace the clutch plates as a set.



#### Clutch plate warpage limit 0.1 mm (0.0039 in)

- 3. Measure:
- assembly width (a) of the friction plates and clutch plates

Out of specification  $\rightarrow$  Adjust.



Assembly width 42.4 ~ 43.0 mm (1.67 ~ 1.69 in)

NOTE: \_\_\_\_

Perform the thickness measurement without applying the oil.

- a. Assembly width adjusted by clutch plate ① and ②.
- b. Select the clutch plate from the following table.

#### Clutch plate (1)

Part No.	Thickness	
4B1-16324-00	1.6 mm (0.062 in)	
5VY-16325-00	2.0 mm (0.079 in)	STD
4B1-16325-00	2.3 mm (0.091 in)	

Clutch plate 2

Part No.	Thickness	
5VY-16325-00	2.0 mm (0.079 in)	STD
4B1-16325-00	2.3 mm (0.091 in)	













#### NOTE: \_

When adjusting the clutch assembly width [by replacing the clutch plate(s)], be sure to replace the clutch plate (1) fast.

After replacing the clutch plate ①, if specifications cannot be met, replace the clutch plate ②.

-----

## CHECKING THE CLUTCH SPRINGS

#### (YZF-R1LE)

The following procedure applies to all of the clutch springs.

- 1. Check:
  - clutch spring Damage → Replace the clutch springs as a set.
- 2. Measure:
  - clutch spring free length (a)
    Out of specification → Replace the clutch springs as a set.



Clutch spring free length 43.8 mm (1.72 in) <Limit>: 41.6 mm (1.64 in)



#### EAS00284

#### CHECKING THE CLUTCH HOUSING (YZF-R1LE)

- 1. Check:
  - clutch housing dogs
    Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

#### NOTE: \_

Pitting on the clutch housing dogs will cause erratic clutch operation.

- 2. Check:
  - bearing Damage/wear → Replace the bearing and clutch housing.

**CLUTCH** 











#### **CHECKING THE PRESSUR PLATE 2**

- (YZF-R1LE)
- 1. Check:
  - pressure plate 2 Cracks/damage  $\rightarrow$  Replace.

#### EAS00285 **CHECKING THE CLUTCH BOSS** (YZF-R1LE)

- 1. Check:
  - clutch boss splines Damage/pitting/wear  $\rightarrow$  Replace the clutch boss.

#### NOTE:

Pitting on the clutch boss splines will cause erratic clutch operation.

- 2. Check:
  - clutch boss Cracks/damage  $\rightarrow$  Replace.

EAS00286

**CHECKING THE PRESSURE PLATE 1** (YZF-R1LE)

- 1. Check:
  - pressure plate (1) Cracks/damage  $\rightarrow$  Replace.
  - bearing (2) Damage/wear  $\rightarrow$  Replace.











# CHECKING THE PULL LEVER SHAFT AND PULL ROD

(YZF-R1LE)

- 1. Check:
  - pull lever shaft pinion gear teeth 1
  - pull rod teeth (2)
    Damage/wear → Replace the pull rod and pull lever shaft pinion gear as a set.
- 2. Check:
  - pull rod bearing Damage/wear → Replace.

#### **INSTALLING THE CLUTCH**

(YZF-R1LE)

- 1. Install:
  - clutch housing ①
  - conical spring washer
- thrust plate 2

#### NOTE: \_

Align the projection of clutch housing (a) and hollow of the oil pump drive gear (b).

- 2. Install:
  - pressure plate 2 (1)
  - clutch boss (2)

#### NOTE: \_

Fit the groove (a) of the pressure plate 2 to the projection (b) of the clutch boss to assemble.











- 3. Install:
- spring ①
- clutch boss nut 
  <u>New</u>

🔌 95 Nm (9.5 m•kg, 69 ft•lb)

#### NOTE: \_

• Put the spring detent (a) into the groove of the pressure plate 2.

Assemble so that each spring detent (a) is positioned in a different groove.

- While holding the clutch boss ③ with the clutch holding tool ④, tighten the clutch boss nut.
- Lock the threads on the clutch boss nut by staking them with a drift punch at the point aligned with the groove in the axle.



Universal clutch holder 90890-04086, YM-91042

- 4. Install:
- clutch damper spring seat ①
- clutch damper spring (2)

#### NOTE: \_

Install the clutch damper spring as shown in the illustration.

- 5. Lubricate:
  - friction plates
  - clutch plates
    - (with the recommended lubricant)

Recommended lubricant Engine oil

CLUTCH











- 6. Install:
  - friction plate 3
  - friction plate 2
  - clutch plate 3
  - clutch plate 2
  - clutch plate 1 (1)

#### NOTE:

Assemble the friction plates and clutch plates according to the installation order.

- 7. Install:
  - friction plate 1 (1)

#### NOTE: \_

Install the last friction plate shifting half phase.

- 8. Install:
  - bearing
  - pull rod
  - pressure plate 1 (1)

#### NOTE: \_

Align the punch mark b on the pressure plate with the punch mark a on the clutch boss.

- 9. Install:
- clutch springs
- clutch spring bolts ①

10 Nm (1.0 m•kg, 7.2 ft•lb)

#### NOTE: \_\_\_\_

Tighten the clutch spring bolts in stages and in a crisscross pattern.





10.Install:

pull lever

#### NOTE: \_

Install the pull lever with the " $\bigcirc$ " mark facing toward upper side.

- 11.Install:
  - clutch cover
- clutch cover gasket New

#### NOTE: \_

- Install the pull rod so that the teeth a face towards the rear of the vehicle. Then, install the clutch cover.
- Apply oil onto the bearing.
- Apply molybdenum disulfide grease onto the pull rod.
- When installing the clutch cover, push the pull lever and check that the punch mark (a) on the pull lever aligns with the mark (b) on the clutch cover. Make sure that the pull rod teeth and pull lever shaft pinion gear are engaged.

- 12.Tighten:
- clutch cover bolts ①
  [2] 2 Nm (1.2 m•kg, 8.7 ft•lb)
- clutch cover bolt ②
  [>k 12 Nm (1.2 m•kg, 8.7 ft•lb)]
  LOCTITE®

#### NOTE: \_

Tighten the clutch cover bolts in a stages and in a crisscross pattern.

- 13.Adjust:
  - clutch cable free play Refer to "ADJUSTING THE CLUTCH CABLE FREE PLAY" in chapter 3.





#### YZF-R1V/YZF-R1VC/YZF-R1LEV/YZF-R1LEVC 2006 WIRING DIAGRAM

(1) Main switch 2 A.C. magneto3 Rectifier/regulator (4) Fuse (main) (5) Fuse (backup) 6 Battery  $\overline{7}$  Fuse (fuel injection) (8) Starter relav (9) Starter motor 10 Starting circuit cut-off relay (11) Neutral switch (12) Sidestand switch (13) Fuel pump (14) E.C.U (15) Ignition coil #1 (16) Ignition coil #2 (17) Ignition coil #3 (18) Ignition coil #4 (19) Spark plug 20 Injector #1 (2) Injector #2 2 Injector #3 23 Injector #4 24 Air induction system solenoid 25 Sub-throttle position sensor 26 EXUP servo motor (27) Speed sensor 28 Coolant temperature sensor 29 Intake air temperature sensor 30 Crankshaft position sensor (31) Throttle position sensor (32) Intake air pressure sensor 3 Atmospheric pressure sensor 3 Cylinder identification sensor 35 Lean angle sensor 36 Meter assembly 37 Fuel level warning light (38) Oil level warning light 39 Neutral indicator light 40 Tacho meter (41) Shift timing indicator light (42) Multi function meter (43) Engine trouble warning light 44 Coolant temperature indicator light (45) Hi beam indicator light (46) Turn signal indicator light (left) (47) Turn signal indicator light (right) (48) Meter light (49) Oil level switch 60 Right handlebar switch (51) Front brake light switch 52 Engine stop switch 53 Start switch 54 Turn signal relay (55) Left handlebar switch 56 Dimmer switch 67 Horn switch

58 Clutch switch 69 Turn signal switch 60 Horn (61) Front turn signal/ position light (left) 62 Front turn signal/ position light (right) 63 Rear turn signal light (left) 64 Rear turn signal light (right) 65 Headlight 66 Auxiliary light 67 License plate light 68 Rear brake light switch 69 Tail /brake light (70) Headlight relay (on/off) (71) Headlight relay (dimmer) (72) Fuse (ignition) (73) Fuse (signal) (74) Fuse (headlight) 75 Radiator fan motor relay 76 Fuse (radiator fan motor left) (7) Fuse (radiator fan motor right) (78) Radiator fan motor 2 (79) Radiator fan motor 1 (80) Ground

#### COLOR CODE

-			_
Β	Black	G/Y Green/Yellow	1
Br	Brown	Gy/B Gray/Black	
Ch	Chocolate	Gy/G Gray/Green	
Dg	Dark green	Gy/R Gray/Red	
G	Green	L/B Blue/Black	
Gy	Gray	L/R Blue/Red	
L	Blue	L/W Blue/White	
Lg	Light green	L/Y Blue/Yellow	
0	Orange	O/B Orange/Black	<
Ρ	Pink	O/G Orange/Green	n
R	Red	P/W Pink/White	
Sb	Sky blue	R/B Red/Black	
W	White	R/G Red/Green	
Υ	Yellow	R/L Red/Blue	
B/G	Black/Green	R/W Red/White	
B/L	Black/Blue	R/Y Red/Yellow	
B/R	Black/Red	Sb/W Sky blue/White	е
B/W	Black/White	W/B White/Black	
B/Y	Black/Yellow	W/R White/Red	
Br/G	Brown/Green	W/Y White/Yellow	
Br/L	Brown/Blue	Y/B Yellow/Black	
Br/R	Brown/Red	Y/G Yellow/Green	۱
Br/W	Brown/White	Y/L Yellow/Blue	
G/B	Green/Black	Y/R Yellow/Red	
G/R	Green/Red	Y/W Yellow/White	
G/W	Green/White		



YAMAHA MOTOR CO., LTD. 2500 SHINGAI IWATA SHIZUOKA JAPAN

### YZF-R1V/YZF-R1VC/YZF-R1LEV/YZF-R1LEVC 2006 WIRING DIAGRAM



